


## Assembly Instruction



## BOBA

model : 1328 YM A86 N2

## User Instructions

- A Seat Height Adjustable**  
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.
- B Multi-Position Tilt Lock**  
Recline to desired position, and flip down lever on left-side to lock. Flip up lever and recline to release tilt-lock.
- C Backrest and Armrest Height**  
Pull the buttons on both side and raise or lower the backrest and armrest, and release button to lock. Adjust height to adequately support elbows to take strain off shoulders.
- D Seat Depth Adjustment**  
Pull the lever under the right-side of the seat to adjust fore and aft position. Adjust such that the front edge is not pressing on the calves while your back is resting on backrest.

