





Assembly Instructions



User Instructions


Models
303B NA A00 Y

- A** Height-Adjustable Seat
Press any one of the 3 buttons under the seat to raise or lower the seat.



MERRYFAIR®

Assembly Instructions




User Instructions

Models

304B NA A00 Y

A Height-Adjustable Seat


Press any one of the 2 buttons under the seat to raise or lower the seat.




MERRYFAIR®

Assembly Instructions


1



2



3




Models
305 NA A00 Y


User Instructions

A Height-Adjustable Seat

Press any one of the 2 buttons under the seat to raise or lower the seat.



Assembly Instructions




User Instructions

Models

306B NA A00 Y



A Height-Adjustable Seat

Press any one of the 2 buttons under the seat to raise or lower the seat.



MERRYFAIR®


Assembly Instructions



User Instructions

Models
300B NA A00 Y

- A** Height-Adjustable Seat
Press any one of the 3 buttons under the seat to raise or lower the seat.



MERRYFAIR®